



CLOAK INSTALLATION: OUTSIDE CORNERS

1. Install Hyload Flashing membrane into block back-up wall per plans and specifications. Install membrane to the corner of back-up wall.

2. Cloaks are installed when the bricks are laid. Adhere membrane to cloak using Hyload Flashing Membrane Adhesive.

